



1. Set the IP Address of the Sentinel Modbus/TCP IO-LINK Master Module

Method 1: Set the IP Address via Sentinel “DhcpTool” IP Address Assignment Software


1. First, download “DhcpTool V1.2” from the Sentinel official website and install it (**Windows 10 or above only**). Open the software.



2. Connect the Sentinel Modbus/TCP IO-LINK master module to the PC. Then set the module IP DIP switches to “0xFF” (on the right-side window: set ADDR_H = F and ADDR_L = F, refer to the manual). This means “DHCP mode: waiting for IP assignment after power-on.” After switching, power-cycle the module. At this time, the **BUS red LED will flash**. Then click “Detect available ports” in the software, select the local port, and click “Connect Port.”



3. The lower area will display the scanned Sentinel Modbus/TCP IO-LINK master module(s), and the front field corresponds to the **MAC address**.




4. Enter the IP address under “IP Address”, for example **192.168.0.20**, then click “Set IP Address” in the upper-left corner. After that, a **green IP address** will appear under “Status” behind the module, indicating the IP configuration is complete. You may close the software. After the IP is set, the module **BUS red LED will stop flashing**.

After configuration:

- You can set the DIP switches to **0x00**, meaning “run with the last DHCP-assigned IP address.” Then after each power cycle, the module will use the previously assigned address (i.e., **192.168.0.20**).


- Alternatively, the DIP switches can be set to **0x01–0xFE**. In this case, the **first three octets** (network segment) follow the DHCP assignment, and the **fourth octet** follows the DIP switch value.

Example: set **ADDR_H = 1** and **ADDR_L = 4**; then the module IP address will be **192.168.0.20**.



Method 2: Set the IP Address via Third-Party Software



- In this example, AB's **"Bootp-DHCP Tool"** is used. Before setting, first set the module IP DIP switches (ADDR_H, ADDR_L on the right-side window; refer to the manual) to **0xFF**, meaning **"DHCP mode: waiting for IP assignment after power-on."** After switching, power-cycle the module. The **BUS red LED will flash**. Open the software, select the appropriate NIC on the PC, and click **"OK."**



- Double-click the detected module, enter the IP address to be set (**the module IP and the PC IP must be in the same subnet**), and click **"OK."** After the setting is completed, the module **BUS red LED will stop flashing**.

After configuration:

- Set the DIP switches to **0x00** to run with the last DHCP-assigned IP after each power cycle.
- Or set to **0x01–0xFE**: the first three octets follow DHCP assignment; the fourth octet follows the DIP switch value.



New Entry [X]

Server IP Address: 192.168.0.15

Client Address (MAC): 02:98:89:44:55:89

Client IP Address: 192 . 168 . 0 . 10

Hostname:

Description:

OK Cancel



BootP DHCP EtherNet/IP Commissioning Tool [-] [□] [X]

File Tools Help

Add Relation Discovery History Clear History

Ethernet Address (MAC)	Type	(hr:min:sec)	#	IP Address	Hostname
02:98:89:44:55:89	DHCP	11:38:06	5	192.168.0.10	

Entered Relations

Ethernet Address (MAC)	Type	IP Address	Hostname	Description
02:98:89:44:55:89	DHCP	192.168.0.10		



Errors and warnings

Sent 192.168.0.10 to Ethernet address 02:98:89:44:55:89

Relations 1 of 256

2. Open XG5000 and Create a New Project

Open **XG5000**, create a new project, select the corresponding PLC (this example uses **XGB series: XBC-DN32U**), and customize a **Project Name**. Click **“Confirm.”**



3. Configure PLC Ethernet (FEnet) Parameters

Double-click “NewPLC [BOS1 Built-in FEnet]”. (Cnet = Modbus RTU, FEnet = Modbus TCP.) Set the IP address and Subnet mask.

In this example, the PLC IP address is **192.168.1.2**.

设定-FNet ×

基本 设置 Host表设定 FTP/SNTP 设置

TCP/IP设定

站号:

媒体: 端口1:
端口2:

IP地址:

子网掩码:

网关:

DNS服务器:

DHCP 准备 OPC UA

专用联机个数: (1 - 16)

接收超时时间设定

客户端: x1s

服务器: x1s

驱动器设定

服务器模式:


4. Add a P2P Communication Item

Right-click “FEnet” → “Add Item” → “P2P Communication” → click “Confirm.”



5. Open P2P Channel

Double-click “P2P Channel” on the left.




6. Configure the P2P Driver

Set “P2P Driver” to “Modbus TCP Client.”

Set “Remote Station IP Address” to the IP address of the connected Sentinel IO-LINK master

module. Click “OK.”



7. Configure P2P Block for Reading IO-Link Input Data (Segment 1)

Double-click “P2P Block.” Select **Channel 0**, set the driver to “**Modbus TCP client.**”

To read IO-Link data:

- P2P Function: **READ**
- Start condition: **F00090** (20 ms clock)
- Mode: **2. Continuous**
- Data type: **WORD**
- Number of variables: **1**
- **Data Size**: set to the amount of data to read (maximum **125**)

Because Sentinel IO-Link master input data occupies **Word[0]–Word[132]** (a total of **133 words**; see the appendix for mapping), it cannot be read in one transaction. Therefore, split into two reads. For the first segment, set **Data Size = 85** words to read all input data up to and including

Port 5.

索引	E-邮件	通道	设定驱动器	Header	P2P功能	启动条件	方式
0	<input type="checkbox"/>						
1	<input type="checkbox"/>						
2	<input type="checkbox"/>						
3	<input type="checkbox"/>						
4	<input type="checkbox"/>						
5	<input type="checkbox"/>						
6	<input type="checkbox"/>						
7	<input type="checkbox"/>						
8	<input type="checkbox"/>						
9	<input type="checkbox"/>						
10	<input type="checkbox"/>						



索引	通道	设定驱动器	Header	P2P功能	启动条件	方式	数据类型	变 ^
0	0	Modbus TCP client		READ	F00090	2.连续	WORD	
1								
2								

索引	变量个数	数据大小	相对站	相对站号	Frame	设定	变量设定内容
0	1		<input checked="" type="checkbox"/>	0		设定	
1						设定	
2						设定	

8. Set Read Parameters (Segment 1)

Click **“Setting”**. In the popup dialog:

- **Save Area**: set to **P0100** (store the first 85 input words starting from P0100)
- **Read Area**: **30000**, hexadecimal **0x30000**
Click **OK/Confirm**.

变量设定

对立PLC内容设置

对立 CPU 系列: 按照产品查看

对立 CPU 类型:

读取区域: 远程地址
保存区域: Local Address (NewPLC)

	读取区域	保存区域	地址
1	0x30000	P0100	N01313

确认 取消



相对站号	Frame	设定	变量设定内容
0		设定	个数:1 READ1:0x30000, SAVE1:P0100

9. Configure Reading IO-Link Input Data (Segment 2)

Add another **Channel 0** with the same settings, but set:

- **Data Size = 48** (read the remaining input words of the IO-Link master)

通道	设定驱动器	Header	P2P功能	启动条件	方式	数据类型
0	Modbus TCP client		READ	F00090	2.连续	WORD
0	Modbus TCP client		READ	F00090	2.连续	WORD

索引	数据类型	变量个数	数据大小	相对站	相对站号	Frame	设定	变量设定内容
0	WORD	1	85	<input checked="" type="checkbox"/>	0		设定	个数:1 READ1:0x30000, SAV
1	WORD	1	48	<input checked="" type="checkbox"/>	0		设定	

10. Set Read Parameters (Segment 2)

Click **"Setting"**. In the popup dialog:

- **Save Area: P200** (store the latter 48 input words starting from P200)

- **Read Area: 30085**, converted to hex **0x30055**

Click **OK/Confirm**.



11. Configure Writing IO-Link Output Data (Split into Two Writes)

Similarly, for writing output data (see the appendix):

The output occupies **Word[0]–Word[127]** (a total of **128 words**). Since the maximum data size is **120**, it cannot be fully written in one transaction either, so you must write it in two operations.

Create two new channels as follows:

- Data size: **64** each time (write the first half of the IO-Link output data, then write the second half).

索引	E-邮件	通道	设定驱动器	Header	P2P功能	启动条件	方式
0	<input type="checkbox"/>	0	Modbus TCP client		READ	F00090	2. 连续
1	<input type="checkbox"/>	0	Modbus TCP client		READ	F00090	2. 连续
2	<input type="checkbox"/>	0	Modbus TCP client		WRITE	F00090	2. 连续
3	<input type="checkbox"/>	0	Modbus TCP client		WRITE	F00090	2. 连续


2. 连续	WORD	1	64	<input checked="" type="checkbox"/>	0		设定
2. 连续	WORD	1	64	<input checked="" type="checkbox"/>	0		设定

12. Set Write Parameters

Click **“Setting”** and set:

- Read area (PLC side data source) **P300** and **P400**


- From **P300**, store the first 48 output words; target area **40000**, hex **0x40000**
 - From **P400**, store the latter 48 output words; target area **40064**, hex **0x40040**
- Click **OK/Confirm**.



数	数据大小	相对站	相对站号	Frame	设定	变量设定内容
	85	<input checked="" type="checkbox"/>	1		设定	个数:1 READ1:0x30000, SAVE1:P0100
	48	<input checked="" type="checkbox"/>	1		设定	个数:1 READ1:0x30055, SAVE1:P0200
	64	<input checked="" type="checkbox"/>	1		设定	个数:1 READ1:P0300, SAVE1:0x40000
	64	<input checked="" type="checkbox"/>	1		设定	个数:1 READ1:P0400, SAVE1:0x40040

13. Open I/O Parameters

Double-click “I/O Parameters.”



14. Add Hardware Modules

According to the PLC hardware configuration, add the hardware modules (in this example, there are digital modules).



15. Go Online (Connect)



Click **Online** → **Connect**.



16. Enable P2P Link in Communication Module Settings (Before First Download)

Before the first download:

Right-click **FENet** → **Communication Module Settings** → **Enable Link (HS Link, P2P)** → check **“P2P 2”** → click **“Confirm.”**




17. Download to PLC and Run

Before downloading, there must be program content in **newprogram**, otherwise downloading is not possible.

Before downloading:


1. Switch the LS PLC to **STOP** mode
2. Click **Online** → **Write**

3. After writing is completed, switch the PLC to **RUN**



18. Monitor Device Data

Click **Online** → **Connect**, then click **Monitor** → **Device Monitor**.



NewPLC - 设备监控 - [P]

The screenshot shows the 'Device Monitor' window with a data table. The table has 11 columns labeled 0 through 9 and 14 rows labeled P0060 through P0190. The row for P0100 is highlighted, showing the following values: ED7F, 0105, 0201, 0402, 0100, 0000, 0000, 0000, 0000, 0000.

	0	1	2	3	4	5	6	7	8	9
P0060	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0070	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0080	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0090	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0100	ED7F	0105	0201	0402	0100	0000	0000	0000	0000	0000
P0110	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0120	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0130	0000	0000	0000	0000	0000	0000	0000	04F0	0000	0000
P0140	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0150	0000	0000	0000	FF26	0000	0185	FF00	0000	0000	0000
P0160	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0170	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0180	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
P0190	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000

Appendix

A1. IO-LINK Process Data Input (Occupies 133 Words)

Supports function code **F04 (Read Input Registers)**

Modbus引用编号 WORD	Modbus数据地址 WORD	IO-LINK字节 BYTE	描述																		
30001	0	Byte0	8位代表8个端口当前IO-LINK状态: 1正常通信, 0未通信 <table border="1"> <tr> <td>位</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> <tr> <td>端口</td> <td>C8</td> <td>C7</td> <td>C6</td> <td>C5</td> <td>C4</td> <td>C3</td> <td>C2</td> <td>C1</td> </tr> </table>	位	7	6	5	4	3	2	1	0	端口	C8	C7	C6	C5	C4	C3	C2	C1
		位	7	6	5	4	3	2	1	0											
端口	C8	C7	C6	C5	C4	C3	C2	C1													
		Byte1	8位代表8个端口IO-LINK断线记录: 1有过断线, 0未有过断线 <table border="1"> <tr> <td>位</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> <tr> <td>端口</td> <td>C8</td> <td>C7</td> <td>C6</td> <td>C5</td> <td>C4</td> <td>C3</td> <td>C2</td> <td>C1</td> </tr> </table>	位	7	6	5	4	3	2	1	0	端口	C8	C7	C6	C5	C4	C3	C2	C1
位	7	6	5	4	3	2	1	0													
端口	C8	C7	C6	C5	C4	C3	C2	C1													
30002	1	Byte2	C1端口断线次数																		
		Byte3	C2端口断线次数																		
30003	2	Byte4	C3端口断线次数																		
		Byte5	C4端口断线次数																		
30004	3	Byte6	C5端口断线次数																		
		Byte7	C6端口断线次数																		
30005	4	Byte8	C7端口断线次数																		
		Byte9	C8端口断线次数																		
30006 - 30021	5 - 20	Byte10 - Byte41	C1端口过程输入数据 (32Byte)																		
30022 - 30037	21 - 36	Byte42 - Byte73	C2端口过程输入数据 (32Byte)																		
30038 - 30053	37 - 52	Byte74 - Byte105	C3端口过程输入数据 (32Byte)																		
30054 - 30069	53 - 68	Byte106 - Byte137	C4端口过程输入数据 (32Byte)																		
30070 - 30085	69 - 84	Byte138 - Byte169	C5端口过程输入数据 (32Byte)																		
30086 - 30101	85 - 100	Byte170 - Byte201	C6端口过程输入数据 (32Byte)																		
30102 - 30117	101 - 116	Byte202 - Byte233	C7端口过程输入数据 (32Byte)																		
30118 - 30133	117 - 132	Byte234 - Byte265	C8端口过程输入数据 (32Byte)																		

A2. IO-LINK Process Data Output (Occupies 128 Words)

Supports function codes:

- **F03 (Read Holding Registers)**
- **F16 (Write Holding Registers)**
- **F23 (Read/Write Holding Registers)**

Modbus引用编号 WORD	Modbus数据地址 WORD	IO-LINK字节 BYTE	描述
40001 - 40016	0 - 15	Byte0 - Byte31	C1端口过程输出数据 (32Byte)
40017 - 40032	16 - 31	Byte32 - Byte63	C2端口过程输出数据 (32Byte)
40033 - 40048	32 - 47	Byte64 - Byte95	C3端口过程输出数据 (32Byte)
40049 - 40064	48 - 63	Byte96 - Byte127	C4端口过程输出数据 (32Byte)
40065 - 40080	64 - 79	Byte128 - Byte159	C5端口过程输出数据 (32Byte)
40081 - 40096	80 - 95	Byte160 - Byte191	C6端口过程输出数据 (32Byte)
40097 - 40112	96 - 111	Byte192 - Byte223	C7端口过程输出数据 (32Byte)
40113 - 40128	112 - 127	Byte224 - Byte255	C8端口过程输出数据 (32Byte)